

TROUBLESHOOTING

TROUBLESHOOTING		
TROUBLE	PROBABLE CAUSE	SOLUTION
• Power light not illuminated.	☛ Unit not plugged in.	✓ Plug in Unit.
• Water leaks from tank.	☛ Tank rubber ring is missing. ☛ Cap not tight enough. ☛ Tank water is Hot.	✓ Remove tank cap and replace or reposition ring. ✓ Tighten the cap. ✓ Fill with cool water only. ✓ Do not move when full.
• Crack in Tank.	☛ Hot water will cause tank to pressurize. ☛ Tanks will crack if hit or dropped.	✓ Fill with cool water only. ✓ Handle tank with Care.
• Film on tank.	☛ Mineral deposits.	✓ Clean/disinfect tank as instructed in weekly cleaning instructions.
• Fan on, but no Mist.	☛ Volume too low. ☛ Might be running out of water.	✓ Turn up volume control. ✓ Fill tank with cool water.
• Appearance of minerals or "white dust".	☛ Tap water contains minerals that collect inside your humidifier. When the minerals are released into the air they often appear as white dust on your furniture.	✓ Use distilled water in your humidifier. This will help reduce the precipitation of minerals or "white dust".

FREQUENTLY ASKED QUESTIONS

FREQUENTLY ASKED QUESTIONS	
Question	Answer
• What are the variables that affect run time?	The estimated run time for this humidifier is based on average room conditions. The actual run time of your humidifier is dependent on numerous variables such as: ✓ Air exchange in the room where the humidifier is placed. ✓ Room construction of the room where the humidifier is placed. ✓ Temperature of the room where the humidifier is placed. ✓ Humidity levels in the room where the humidifier is placed. ✓ Movement of occupants and the opening and closing of doors in the room where the humidifier is placed. ✓ Home furnishings in the room where the humidifier is placed.
• How do I remove film on water tank?	✓ See Daily Maintenance instructions. Regular cleaning is recommended.
• How can I extend the run time?	✓ Run your unit on the lowest setting. ✓ If your unit has electronics, set it to your desired humidity level. The unit will turn on and off, which will extend the run time. ✓ Fill the tank all the way full, place it on the base, let the water empty into the base until it stops bubbling, then refill the tank full again. This ensures maximum water capacity and will extend run time.

WARRANTY INFORMATION

1 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, fire, flood, hurricanes and tornadoes.

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-546-5637 and a convenient service center address will be provided to you.

In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-546-5637 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 5975 Falbourne Street, Mississauga, Ontario L5R 3V8. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. **PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**

Holmes

Owner's Guide

HM500TG

☎ INFO HOT-LINE: If, after reading this owner's guide you have any questions or comments, please call 1-800-546-5637 and a Customer Service Representative will be happy to assist you.



Ultrasonic Cool Mist Humidifier

PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

Holmes

Manual del propietario

HM500TG

☎ LÍNEA DIRECTA DE INFORMACIÓN: Si tiene alguna pregunta o comentario luego de haber leído este manual, llame al 1-800-546-5637 y un Representante del Servicio al Consumidor lo asistirá cordialmente.



Ultrasonic Con Rocío Fresco Humidificador

LEA Y CONSERVE ESTAS INSTRUCCIONES IMPORTANTES

DIAGNÓSTICO DE PROBLEMAS

DIAGNÓSTICO DE PROBLEMAS		
PROBLEMA	POSIBLE CAUSA	SOLUCIÓN
• La luz de encendido no ilumina.	☛ La unidad no está enchufada.	✓ Enchúfela.
• Fugas de agua del tanque.	☛ Falta el anillo de caucho del tanque. ☛ La tapa no está suficientemente ajustada. ☛ El tanque de agua está caliente.	✓ Quite la tapa del tanque y reemplace o coloque correctamente el anillo. ✓ Ajustar bien la tapa. ✓ Llene sólo con agua fría. ✓ No lo mueva cuando esté lleno.
• El tanque está agrietado.	☛ El agua caliente causará presión en el tanque. ☛ El tanque se agrietará si es golpeado o está goteando.	✓ Llene con agua fría solamente. ✓ Maneje el tanque con cuidado.
• Hay residuos en el tanque.	☛ Hay depósitos minerales.	✓ Limpie el tanque/desinfecte el tanque tal como se indica en las instrucciones de limpieza semanal.
• Ventilador encendido, sin rocío.	☛ Volumen muy bajo. ☛ Se está quedando sin agua.	✓ Aumente el control de volumen. ✓ Llene el tanque con agua fría.
• Apariencia de minerales o "polvo blanco".	☛ El agua del grifo contiene minerales que se acumulan en el interior de su humidificador. Cuando los minerales se liberan en el aire a menudo aparecen en forma de polvo blanco en sus muebles.	✓ Utilice agua destilada en el humidificador. Esto ayudará a reducir la precipitación de minerales o "polvo blanco".

PREGUNTAS FRECUENTES

PREGUNTAS FRECUENTES	
PREGUNTAS	RESPUESTAS
• Cuáles son las variables que afectan el tiempo de funcionamiento?	El tiempo de funcionamiento estimado de este humidificador está basado en las condiciones ambientales promedio. El tiempo de funcionamiento actual de su humidificador depende de varios factores tales como : ✓ El intercambio de aire en el cuarto donde se encuentra el humidificador. ✓ La estructura del cuarto donde se encuentra el humidificador. ✓ La temperatura del cuarto donde se encuentra el humidificador. ✓ Los niveles de humedad en el cuarto donde se encuentra el humidificador. ✓ La actividad de los ocupantes y la secuencia en que se abren y cierran las puertas del cuarto donde se encuentra el humidificador. ✓ El número de muebles presentes en el cuarto donde se encuentra el humidificador.
• Cómo quito la película del tanque de agua?	✓ Consulte las instrucciones diarias de mantenimiento. Se recomienda una limpieza regular.
• Cómo puedo extender el tiempo de funcionamiento?	✓ Haga funcionar la unidad en el modo más bajo. ✓ Si su unidad tiene electrónicos, ajústela al nivel de humedad deseado. La unidad se encenderá y apagará, extendiendo el tiempo de funcionamiento. ✓ Llene el tanque al máximo, colóquelo en la base, deje que el agua se vacíe en la base hasta que deje de burbujear, luego llene nuevamente el tanque al máximo. Esto asegura una capacidad máxima de agua que extenderá el tiempo de funcionamiento.

© 2016 Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions. Todos los derechos reservados. Distribuido por Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions, Boca Raton, Florida 33431. Sunbeam Products, Inc. es una subsidiaria de Newell Brands Inc. (NYSE: NWL)

136307 Rev B
GCDS-H0146611-JC

HM500-TG_16ESM1

Impreso en China

